

F-R200 Industrial Router User Manual	Document Version	Page
	V2.0.0	
	Product Name: F-R200	Total:54

# F-R200 Industrial Router User Manual



[Xiamen Four-Faith Communication Technology Co., Ltd.](#)

Add: Floor 11, Area A06, No 370, chengyi street, Jimei, Xiamen

Tel: +86 592-5907276 Fax:+86 592-5912735

Web:en.four-faith.com

## Files Revised Record

Date	Version	Remark	Author
2017.03.10	V1.0.0	Initial version	ZC/WSC
2017.10.10	V2.0.0	Change of company address	LXP

## Copyright Notice

All contents in the files are protected by copyright law, and all copyrights are reserved by HongKong Four-Faith Communication Technology Co., Ltd. Without written permission, all commercial use of the files from Four-Faith are forbidden, such as copy, distribute, reproduce the files, etc., but non-commercial purpose, downloaded or printed by individual (all files shall be not revised, and the copyright and other proprietorship notice shall be reserved) are welcome.

## Trademark Notice

Four-Faith、四信、、、 are all registered trademarks of HongKong Four-Faith Communication Technology Co., Ltd., illegal use of the name of Four-Faith, trademarks and other marks of Four-Faith is forbidden, unless written permission is authorized in advance.



Note: There may be different components and interfaces in different model, please in kind prevail.

# Contents

Chapter 1 Brief Introduction of Product.....	7
1.1 General.....	7
1.2 Working Principle.....	8
Chapter 2 Installation Introduction.....	9
2.1 General.....	9
2.2 Encasement List.....	9
2.3 Installation and Cable Connection.....	9
2.4 Power.....	14
2.5 Indicator Lights Introduction.....	14
2.6 Reset Button Introduction.....	15
Chapter 3 Configuration and Management.....	16
3.1 Configuration Connection.....	16
3.2 Login the Router Web GUI.....	16
3.2.1 Configure the PC IP address(There are two ways).....	16
3.2.2 Login the router Web GUI.....	18
3.3 Management and Configuration.....	19
3.3.1 Network.....	19
3.3.1.1 Internet Setting.....	19
3.3.1.2 LAN Setting.....	24
3.3.1.3 Wireless Setting.....	25
3.3.2 Firewall.....	27
3.3.2.1 Port Forwarding.....	28
3.3.2.2 DMZ.....	28
3.3.2.3 URL Filter.....	29
3.3.4 VPN.....	29
3.3.4.1 L2TP.....	29
3.3.4.2 PPTP.....	31
3.3.4.3 GRE.....	32
3.3.4.4 IPsec.....	34
3.3.4.5 OpenVPN.....	38
3.3.5 Advanced.....	39
3.3.5.1 FTP Server.....	39
3.3.5.2 Dynamic DNS.....	39
3.3.5.3 QoS Setting.....	40
3.3.5.4 Remote Management Settings.....	41
3.3.5.5 SNMP.....	42
3.3.5.6 Static Routes.....	44
3.3.5.7 GPS Setting.....	45
3.3.5.8 Serial Setting.....	46
3.3.6 Management.....	47
3.3.6.1 Admin Password.....	47

---

3.3.6.2 System Log Setting.....	48
3.3.6.3 Backup/Restore.....	49
3.3.6.4 Flash Firmware.....	49
3.3.6.5 Sys Log.....	50
3.3.6.6 Attached Setting.....	50
3.3.6.7 Time Setting.....	51
3.3.6.8 Reboot.....	52
3.3.6.9 Logout.....	52
3.3.7 Appendix.....	52


## Chapter 1 Brief Introduction of Product

### 1.1 General

Four-Faith Industrial Router F-R200 is an intelligent 3G/4G routers to provide the necessary M2M applications for all types of terminals.


It adopts high-powered industrial 32-bits CPU and embedded real time operating system. It supports RS232 (or RS485/RS422), Ethernet and WIFI port that can conveniently and transparently connect one device to a cellular network, allowing you to connect to your existing serial, Ethernet and WIFI devices with only basic configuration.

It has been widely used on M2M fields, such as self-service terminal industry, intelligent transportation, smart grid, smart home, industrial automation, intelligent building, public security, fire protection, environment protection, telemetry, finance, POS, water supply, meteorology, remote sensing, digital medical, military, space exploration, agriculture, forestry, petrochemical and other fields etc..



## 1.2 Working Principle

The principle chart of the router is as following:



## Chapter 2 Installation Introduction

### 2.1 General

The router must be installed correctly to make it work properly.


**Warning: Forbid to install the router when powered!**

### 2.2 Encasement List


Name	Quantity	Remark
Router host	1	
Cellular antenna (Male SMA)	2	
WIFI Dual band antenna (Female SMA)	1	
GPS antenna(Male SMA)	1	optional
Network cable	1	
Console cable	1	
RS485 Console cable	1	optional
3PIN Terminal Block	2	
2PIN Terminal Block	1	
Power adapter	1	
Manual CD	1	
Certification card	1	
Maintenance card	1	

### 2.3 Installation and Cable Connection

Stator and routing equipment of screw specification for: M3 \* 5 mm countersunk head screws (black) (optional)



Fixed Size



Router Size


### Installation of SIM/UIM card:

- 1、 Firstly power off the router
- 2、 Unscrewed the screw
- 3、 Press the out button of the SIM/UIM card outlet with a needle object. Then the SIM/UIM card sheath will flick out at once
- 4、 Put SIM/UIM card into the card sheath (Pay attention to put the side which has metal point outside), and insert card sheath back to the SIM/UIM card outlet.
- 5、 Screwed the screw

**Warning: Forbid to install SIM/UIM card when powered!**



Step 2



Step 3



Step 4



Step 5

**Installation of antenna:**

Screw the SMA male pin of the cellular antenna to the female SMA interface of the Router with sign “ANT-1” and “ANT-2”.

Screw the SMA female pin of the WIFI antenna to the male SMA interface of the router with sign “WIFI”.

Screw the SMA female pin of the GPS antenna to the female SMA interface of the router with sign “GPS”.(optional)

Warning: The cellular antenna and the WIFI antenna can not be connected wrongly. And the antennas must be screwed tightly, or the signal quality of antenna will be influenced!

**Installation of cable:**

Insert one end of the network cable into the switch interface with sign“LAN1/LAN2/LAN3/ LAN4”, and insert the other end into the Ethernet interface of user’s device. The signal connection of network direct cable is as follows:

RJ45-1	RJ45-2	Color
1	1	White/Orange
2	2	Orange
3	3	White/Green
4	4	Blue
5	5	White/Blue
6	6	Green
7	7	White/Brown
8	8	Brown



Insert the RJ45 end of the console cable into the RJ45 outlet with sign “console”, and insert the DB9F end of the console cable into the RS232 serial interface of user’s device.

The signal connection of the console cable is as follows:

Console line definition (RS232)					
RJ45	Color	Signal	DB9F	Description	Dir (Router)
1	White/Orange	A	8	RS485-A	Input/Output
2	Orange	B	6	RS485-B	Input/Output
3	White/Green	RXD	2	Receive Data	Output
4	Blue	DCD	1	Data Carrier Detect	Output
5	White/Blue	GND	5	System Ground	
6	Green	TXD	3	Transmit Data	Input
7	White/Brown	DTR	4	Data Terminal Ready	Input
8	Brown	RTS	7	Request To Send	Input



## 2.4 Power

The power range of the router is DC 5~36V.

Warning: When we use other power, we should make sure that the power can supply power above 8W.

We recommend user to use the standard DC 12V/1.5A power.

## 2.5 Indicator Lights Introduction

The router provides following indicator lights: “PWR”, “SYS”, “Online”, “SIM”, “LAN”, “WAN”, “WIFI”, “Signal Strength”.

Indicator Light	State	Introduction
PWR	ON	Router is powered on
	OFF	Router is powered off
SYS	BLINK	System works properly
	OFF	System does not work
Online	ON	Router has logged on network
	OFF	Router hasn't logged on network
SIM	ON	The SIM card has been identified
	OFF	The SIM card is not recognized
LAN	OFF	The corresponding interface of switch is not connected
	ON / BLINK	The corresponding interface of switch is connected /Communicating
WAN	OFF	The interface of WAN is not connected

	ON / BLINK	The interface of WAN is connected /Communicating
WIFI	OFF	WIFI is not active
	ON	WIFI is active
Signal Strength	One Light ON	Signal strength is weak
	Two Lights ON	Signal strength is medium
	Three Lights ON	Signal strength is good


## 2.6 Reset Button Introduction

The router has a “RST” button to restore it to its original factory default settings. When user press the “Reset” button for up to 10s, the router will restore to its original factory default settings and restart automatically.

## 2.7 Flank Interface

Flank Interface as picture below,The router provides 2 Direct Input,1 Direct Output,1 Relay control .

DI	Input ON	5 to 30 VDC
	Input OFF	0 to 3 VDC
DO	Output	< 50mA @ 30VDC
RELAY	Load capability	1A 250VAC/30VDC




## Chapter 3 Configuration and Management

This chapter describes that how to configure and manage the router.

### 3.1 Configuration Connection


Before configuration, you should connect the router to the PC by the provided Ethernet cable or WIFI to configure the router. Connect one side of the Ethernet cable to the router LAN port, and the other side to PC ETH port. If you connect by WIFI, connect to SSID “FOUR-FAITH\_XXXX”(XXXX stands for the last four letters of the default Wireless MAC address in the router) without password.



### 3.2 Login the Router Web GUI


#### 3.2.1 Configure the PC IP address(There are two ways)

##### (1) Obtain an IP address automatically



## (2) Use a given IP address


Configure the PC IP address as 192.168.4.9 (or other IP address in the same subnet), subnet mask as 255.255.255.0 and default gateway as 192.168.4.1. Configure the DNS server as the local DNS server.



### 3.2.2 Login the router Web GUI

The main functions of each menu are described in this chapter. You can access to the router Web GUI through the web browser on the PC. Main menus are as below: Status, Network, Firewall, VPN Setting, Advanced Setting and Management. Click the main menu and you will see the sub menu.

Start IE explorer or other web browser, input the router default IP address 192.168.4.1:90 and press the enter button to access router login Web GUI. You will get the following prompt box to remind you to enter the router default login username and password when you access the Web GUI for the first time.



Four-Faith 四信®

Please Enter Your Username And Password.

Username: admin

Password: .....

Login Reset

Then you will enter the Status page.

## Status

Version	Firmware Version: R200_STD-2.0.1.18 Release Date: 2016-07-27 HW Version: 1.0					
Internet	Connection Type: static IP Address: 192.168.9.9 Gateway: 192.168.9.1 DNS Server: MAC Address: 00:0C:43:28:80:9E OnLine Status: OnLine					
LAN	LAN IP: 192.168.4.1 MAC Address: 00:0C:43:28:80:9E DHCP Server: Enable					
Remote Server	Server IP: 192.168.8.234 Server Port: 9001 Connected Status: disconnected					
2.4G Wireless	Mode: 11bgn Channel: auto Encryption: none SSID: Four-Faith_FFFF MAC Address: FF:FF:FF:FF:FF:FF					
5G Wireless	Mode: 11ac Channel: auto Encryption: none SSID: Four-Faith_5G_FFFF MAC Address: FF:FF:FF:FF:FF:FF					
Storage Devices	<b>Device</b>	<b>Label</b>	<b>Filesystem</b>	<b>Capacity</b>	<b>Used</b>	<b>Percent</b>
	mmcblk0p1	KINGSTON	vfat	29.9G	1.4G	5%
VPN Status						

## 3.3 Management and Configuration

### 3.3.1 Network

The first sub menu in “Network” menu is “Internet Setting”, And you can change the Internet setting according to the instructions. Click “Save & Apply” button and the changes will take effect. Click “Save” button to save the settings but the changes don’t take effect. Click “Reset” button to cancel changes.



#### 3.3.1.1 Internet Setting

Configure “WAN Connection type” to make the router connect to the Internet. And you can get the parameters from the ISP.

**WAN Connection Type:**

Select the corresponding Internet connection type which is provided. WAN connection type includes Static IP, DHCP, PPPoE, 3G connection and LTE connection.

**Mode One: Static IP**

Use this mode if you subscribe optical network or other wired network and configure the IP address, netmask, gateway, DNS server provided by the ISP.

Connection Type

IP Address

Netmask

Gateway

DNS Server

**IP Address:** IP address assigned by the ISP or one you set by your own

**Netmask:** Netmask assigned by the ISP or one you set by your own

**Gateway:** Gateway assigned by the ISP or one you set by your own

**DNS Server:** IP address assigned by the ISP or one you set by your own. Click “+” button to add more.

MTU   (500-1450)

MAC Clone   Enable MAC Clone

**MTU:** Set the appropriate MTU value to make full use of internet throughout.

**MAC Clone:** The selection enable MAC Clone.

**Mode Two: DHCP**

DHCP is the default WAN connection type.

General Settings | **Advanced Settings**

Connection Type

DNS Server

Router obtains the WAN IP address by DHCP and you can set the static DNS server.

General Settings | **Advanced Settings**

MTU  (500-1450)

MAC Clone  Enable MAC Clone

The advanced setting of this mode is the same with static IP mode

### Mode Three: PPPOE

Use this mode if you subscribe ADSL broadband service. Configure username and password provided by the ISP.

General Settings | **Advanced Settings**

Connection Type

User Name

Password

DNS Server

General Settings | **Advanced Settings**

Access Concentrator

Service Name

Keep Alive  Enable  Disable

Keep Online Detection  ▼

Detection Interval

Primary Detection Server

Backup Detection Server

MAC Clone   Enable MAC Clone

Access Concentrator and Server Name, are optional. The other options will be explained below.

#### Mode Four: 3G Connection

General Settings | **Advanced Settings**

Connection Type  ▼

User Name

Password  

DNS Server  

General Settings

Advanced Settings

Operator's APN	<input type="text"/>
Dial Number	*99# UMTS/3G/3.5G ▼
Network Type	Auto ▼
Allow PAP	<input checked="" type="checkbox"/>
Allow CHAP	<input checked="" type="checkbox"/>
Allow MS-CHAP	<input checked="" type="checkbox"/>
Allow MS-CHAPv2	<input checked="" type="checkbox"/>
Keep Online Detection	Ping ▼
Detection Interval	<input type="text" value="60"/>
Primary Detection Server	<input type="text" value="208.67.222.222"/>
Backup Detection Server	<input type="text" value="208.67.220.220"/>
Enable Reboot	<input type="radio"/> Enable <input checked="" type="radio"/> Disable <input type="radio"/> System will reboot when offline
MAC Clone	<input type="checkbox"/> <input checked="" type="checkbox"/> Enable MAC Clone

Save & Apply

Save

Reset

Help

**User Name:** login the Internet  
**Password:** login the Internet  
**Dial Number:** dial number of users' ISP  
**Operator's APN:** access point name of users' ISP  
**Network Type:**

Network Type  ▼

Network type includes Auto, Force 3G, Force 2G, Prefer 3G, Prefer 2G, 3G/2G, Force 4G and 4G/3G/2G.

**Keep Online Detection**

Keep Online Detection	Ping ▼
Detection Interval	<input type="text" value="60"/>
Primary Detection Server	<input type="text" value="208.67.222.222"/>
Backup Detection Server	<input type="text" value="208.67.220.220"/>

This function is used to detect whether the Internet connection is active. if users set it, router will detect the Internet connection automatically. The router will redial immediately to make the obtain active connection When it detects the connection is inactive.

**[Xiamen Four-Faith Communication Technology Co.,Ltd.](http://en.four-faith.com)**

Add: Floor 11, Area A06, No 370, chengyi street, Jimei, Xiamen.China

<http://en.four-faith.com>

Tel: +86 592-5907276

Fax: +86 592-5912735

**Keep Online Connection Type:**

None: No online detection

Ping: Send ping packet to detect the connection. when choosing this method, you should also configure "Detection Interval", "Primary Detection Server IP" and "Backup Detection Server IP" items.

Route: Detect connection with route method. When choosing this method, you should also configure "Detection Interval", "Primary Detection Server IP" and "Backup Detection Server IP" items.

PPP: Detect connection with PPP method. When choosing this method. You should also configure "Detection Interval" item.

**Detection Interval:**

Time interval between two detection , and unit is second.

**Primary Detection Server:**

The server used to response to the router's detection packet. This item is only valid for method "Ping" and "Route".

**Backup Detection Server:**

The backup server used to response to the router's detection packet. This item is only valid for method "Ping" and "Route".

### 3.3.1.2 LAN Setting

#### Local Network

Configure the local area network setting

#### Local Network

Local Address	<input type="text" value="192.168.4.1"/>
Netmask	<input type="text" value="255.255.255.0"/>

**Local Address:** The router IP in the local network

**Netmask:** Netmask assigned by the ISP or one you set by your own

#### DHCP Server Setting(DHCP)

These functions are used to configure dynamic host configuration protocol server setting. The F-R200 router can be a DHCP server. The DHCP server provides a dynamic IP address for every pc automatically. You can configure all of computers to get IP addresses and DNS automatically while DHCP function of the router is selected, and make sure that there is only one DHCP server in the network.

## DHCP Server Setting

DHCP Server  Enable  Disable

Start IP Address  ⓘ (2,255)

Maximum DHCP Users  ⓘ (1,254)

Leasetime  ⓘ Client Lease Time

Save & Apply

Save

Reset

Help

**DHCP Server:** DHCP Sever is enabled by default. If users already have a DHCP server on their network or do not want a DHCP server, select disable. If the DHCP server is enabled, enter the IP address please.

**Start IP Address:** Enter a numerical value for the DHCP server as the starting IP addresses. Please do not start with 192.168.4.1 (the router's own IP address). The start ip of the network must be great than or equal to 192.168.4.2, but less than 192.168.4.254. The default start IP is 192.168.4.100.

**Maximum DHCP Users:** Enter the maximum number of the PCs which users want to assign IP addresses to. The absolute maximum is 253 if 192.168.4.2 is users' starting IP address. The default number is 50.

**Leasetime:** The Leasetime is the amount of time that the dynamic IP address allowed to be used. Enter the leasetime, in minutes, so that the user could "lease" this dynamic IP address. New IP address will be assigned after the leasetime is expired.The default setting is 1440 minutes, which is one day. The configurable value ranges from 0 to 99999.

### 3.3.1.3 Wireless Setting

#### Basic Setting

## 2.4G Setting

General Settings

Advanced Settings

WiFi 2.4G  Enable  Disable

Mode

Channel

Network Name(SSID)

Encryption

Hide SSID

**Enable:** Enable WIFI

**Disable:** Disable WIFI

**Wireless Mode:**

802.11b: Only supports the 802.11b standard wireless devices.

802.11g: Only supports the 802.11g standard wireless devices.

802.11bg: Support 802.11b, 802.11g wireless devices.

802.11bgn: Support 802.11b, 802.11g, 802.11n wireless devices.

**Channel:** There are 13 channels in total, from channel 1 to channel 13. Don't use the same channel with other routers.

**Network Name(SSID):** The SSID is the network name shared in the wireless network. It is case-sensitive and must not exceed 32 alphanumeric characters.

**Encryption:** The F-R200 router contains 6 security modes in total. Encryption is disabled by default. If the mode is changed, click "Save & Apply" to make it effect immediately.

**Hide SSID:**

Uncheck: Broadcast SSID

Check: Hide SSID

Configure wireless network security.

Encryption

Key

**WEP:** WEP is a basic encryption algorithm, which is less secure than WPA. Using of WEP is discouraged due to the weaknesses security, and one of the WPA modes should be used whenever possible. Only use WEP if you have clients that can only support WEP (usually older, 802.11b-only clients).

**WPA Personal/WPA2 Personal/WPA2 Person Mixed:** F-R200 provides 3 types of WPA security protocols,TKIP/AES/TKIP+AES,dynamic encryption keys. TKIP + AES, self-applicable TKIP or AES. WPA Person Mixed, allows WPA Personal and WPA2 Personal client mixed.

**Advanced Settings:**

Please be careful of these configurations, the router will degrade performance because of the incorrect configuration.

General Settings	Advanced Settings
Beacon Interval	<input type="text" value="100"/> ⓘ (1,65535)
DTIM Interval	<input type="text" value="1"/> ⓘ (1,255)
Fragment Threshold	<input type="text" value="2346"/> ⓘ (256, 2346)
RTS Threshold	<input type="text" value="2347"/> ⓘ (64,2347)
MAX Client	<input type="text" value="64"/> ⓘ (1,116)
Transceive Power	<input type="text" value="100%"/> ⓘ (1,100)(%) Percent

**Beacon Interval:** The default is 100. You can enter the value ranges from 1 to 65535, in milliseconds.


**DTIM Interval:** The default is 1. it ranges from 1 to 255, which indicates that the interval of message transmission. The DTIM field is counted down. the router will inform the customer to get the broadcast and multicast messages, then the latest DTIM and DTIM interval will be sent. The clients will be waked up and get the broadcast and multicast messages from the transmitting stations.

**Fragment Threshold:** Keep the value 2346 by default, which ranges from 256 to 2346 Bytes. It indicates the maximum amount of data without division. You should increase Fragment Threshold when the higher packet loss rate occurs. The low fragment threshold may lead to the degrade performance. as a result, we advice you not to change fragment threshold.

**RTS Threshold:** Keep the value 2347 as default setting, which is range from 0 to 2347. A slight modification is allowed if you are in trouble of inconsistent data stream. The RTS/CTS mechanism will not take effect for the amount of network packets is less than preset Threshold. The router sends the RTS frame and data frame to the specific receiving station. After getting the RTS frame, The wireless terminals obtain the specific CTS frame, then transmission is starting.

**MAX Client:** The maximum number of clients, 1-128.

**3.3.2 Firewall**



### 3.3.2.1 Port Forwarding

Port Forwarding allows you to set up public services on your network, such as web servers, ftp servers, e-mail servers, or other specialized Internet applications. Specialized Internet applications are any applications which use Internet access to perform functions such as video conferencing or online gaming.

Editing Rule

Name	<input type="text"/>
Protocol	<input type="text" value=""/>
External IP Address	<input type="text" value="any"/>
Internal IP Address	<input type="text" value=""/>
Internal Port	<input type="text" value="0-65535"/>

[Back to Overview](#) [Save & Apply](#) [Save](#) [Reset](#) [Help](#)

**Names:** Enter the application name in the field.

**Protocol:** Select the appropriate protocol TCP, UDP or Both. Set this to what the application requires.

**External IP Address:** Forward only if sender matches this ip/net (example 192.168.4.0/24).

**Internal IP Address:** Enter the IP Address of the PC which is running the application.

**Internal Port:** Enter the number of the internal port (the port number used by the application).

Click “Save” or “Save & Apply” to complete modification. Click “Reset” to roll back the changes. The shortcut “Help” locates on the lower right corner of the page, click it for more details.

### 3.3.2.2 DMZ

The DMZ (Demilitarized Zone) hosting feature allows one local user to be exposed to the internet for use of a special-purpose service such as internet gaming or videoconferencing. DMZ hosting forwards all the ports at the same time to one PC. The Port Forwarding feature is more secure because it only opens the ports you want to have opened, while DMZ hosting opens all the ports of one computer, exposing the computer so the Internet can see it.

DMZ  Enable  Disable

DMZ Host



To expose one PC to the Internet, select “Enable” and enter the computer's IP address in the DMZ Host IP Address field. To disable the DMZ, keep the default setting: Disable.

Check all values and click “Save & Apply” or “Save” to save your settings. Click the “Reset” to cancel your changes.

### 3.3.2.3 URL Filter

It filters some specific domain address. If you visit the domain address, firewall intercept it.

**Keywords**




 Add



Click “Add” to add more key words.

### 3.3.4 VPN



#### 3.3.4.1 L2TP

L2TP Server

[Xiamen Four-Faith Communication Technology Co.,Ltd.](http://en.four-faith.com)

Add: Floor 11, Area A06, No 370, chengyi street, Jimei, Xiamen.China

<http://en.four-faith.com>

Tel: +86 592-5907276

Page 29 of 54

Fax: +86 592-5912735

L2TP Server Setting

L2TP Client Setting

L2TP Server  Enable  Disable

L2TP Server Local IP

Clients IP Address Range

Enable MPPE Encryption

CHAP Secrets

**L2TP Server Local IP:** Enter the L2TP Server IP address, make sure that the Sever IP is different from LAN IP address.

**Clients IP Address Range:** IP addresses assigned to the Clinets, **xxx.xxx.xxx.xxx-xxx**

**Enable MPPE Encryption:** Use MPPE Force Encryption.

**DNS1, DNS2, WINS1, WINS2:** Set your first DNS, second DNS, first wins, second wins.

**CHAP Secrets:** The usernames and passwords of the clients.

**NOTE:** The Clients IP can't be the same with the IP of DHCP, but outside of the range.

**CHAP Secrets format:** user blank\*blank password blank\*

L2TP Clinet

L2TP Server Setting

L2TP Client Setting

L2TP Client  Enable  Disable

L2TP Server

User Name

Password  

remote local ip

remote local netmask

Nat

Enable MPPE Encryption

Enable Manual Setup

**L2TP Server:** The IP address of L2TP server

**User Name:** The user name which is recognized by the server

**Password:** The password which is corresponding to user name

- remote local ip mask:** The remote local ip address
- remote local netmask:** Netmask assigned by the ISP of remote local ip;
- Nat:** Allow network address translation
- Enable MPPE Encryption:** Use MPPE force encryption.
- Enable Manual Setup:** Configure the IP address manually.

### 3.3.4.2 PPTP

#### PPTP Server

PPTP Server Setting

PPTP Client Setting

PPTP Server  Enable  Disable

PPTP Server Local IP

Clients IP Address Range

Enable MPPE Encryption

DNS1

DNS2

WIN1

WIN2

CHAP Secrets 

#USERNAME	PROVIDER	PASSWORD	IPADDRESS

Save & Apply
Save
Reset
Help

- PPTP Server Local IP:** Enter the PPTP Server IP address, different with LAN IP address.
- Clients IP Address Range:** IP addresses assigned to the clients, **xxx.xxx.xxx.xxx-xxx**
- Enable MPPE Encryption:** Use MPPE Force Encryption.
- DNS1,DNS2,WINS1,WINS2:** Set your first DNS, second DNS, first wins, second wins.
- CHAP Secrets:** The usernames and passwords of the clients.
- NOTE:** The Clients IP can't be the same with the IP of DHCP, but outside of the range.
- CHAP Secrets format:** user blank\*blank password blank\*

#### PPTP Client

PPTP Server Setting

PPTP Client Setting

PPTP Client  Enable  Disable

PPTP Server

User Name

Password  

remote local ip mask

remote local netmask

Nat

Enable MPPE Encryption

Enable Manual Setup

Save & Apply

Save

Reset

Help

**PPTP Server:** The IP address of PPTP server

**User Name:** The user name which is recognized by the server

**Password:** The password which is corresponding to user name

**remote local ip mask:** The remote local ip address

**remote local netmask:** Netmask assigned by the ISP of remote local ip;

**Nat:** Allow network address translation

**Enable MPPE Encryption:** Use MPPE Force Encryption.

**Enable Manual Setup:** Assign the IP address manually.

### 3.3.4.3 GRE

GRE (Generic Routing Encapsulation) encapsulates the network layer protocol(IP , IPX) data packets, it makes these packets can be transferred in the other network layer protocol. GRE uses tunnel technology, which is the third layer protocol of VPN(Virtual Private Network). With GRE you can setup VPN tunnel through GRE protocol. You can setup max 12 tunnels.

### Rules

Name	Peer Wan IP	Peer Tunnel IP	Peer LAN Mask	Local Tunnel IP	Local Mask
------	-------------	----------------	---------------	-----------------	------------

*This section contains no values yet*

 Add

[Save & Apply](#) [Save](#) [Reset](#) [Help](#)

Click “Add” to add rules, just like below.

## GRE Setting

Editing Rule

Name	<input type="text"/>
Peer Wan IP	<input type="text"/>
Peer Tunnel IP	<input type="text"/>
Peer Subnet	<input type="text"/>
Local Tunnel IP	<input type="text"/>

 [Back to Overview](#)

[Save & Apply](#) [Save](#) [Reset](#) [Help](#)

**Name:** The name of GRE rule

**Peer Wan IP:** Enter the GRE Wan IP of peer side

**Peer Tunnel IP:** The GRE tunnel IP of peer side

**Peer Subnet:** The Subnet of peer side, it can not be the same with the local subnet

### 3.3.4.4 IPsec

## IPSec Parameters

Setting IPSec Server and Client

### Global Configuration

#### SETUP

Interfaces for IPsec to	<input type="text" value="%defaultroute"/>
use	
Accept/Offer to support	<input checked="" type="checkbox"/>
NAT	
plutodebug	<input type="text" value="control"/>

### IPsec Connections

This section contains a list of the configured IPsec connections and their current states.

Status	Enable/Disable	Connect/Disconnect	Left	Right
<i>This section contains no values yet</i>				
<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>
<div style="display: flex; justify-content: space-between; align-items: center;"> <span>Server for IPsec</span> <span>Client for IPsec</span> <span>Server for IPsec</span> </div> <div style="display: flex; justify-content: space-between; align-items: center;"> <span>Save &amp; Apply</span> <span>Save</span> <span>Reset</span> <span>Help</span> </div>				

There are two modes are provided, which are “Server for IPsec” and “Client for IPsec”.

#### Server for IPsec:

Left(Local Setting)

## IPSec Parameters

Left(Local Setting) | [Shared](#) | [Right\(Peer Setting\)](#)

### Left Endpoint Options for ipsec\_server

leftid	<input type="text" value="@123"/>
leftsubnets	<input type="text" value="192.168.1.0/24"/>
	<input type="text" value="-- Additional Field --"/> <input type="button" value="Add"/>

Save & Apply
Save
Reset
Help

**leftid:** this is the sign of the local side, you can the id just like “@123”

**leftsubnets:** it is the subnet of the local side, just like “192.168.4.0/24”

**shared:**

## IPSec Parameters

[Left\(Local Setting\)](#) | **Shared** | [Right\(Peer Setting\)](#)

### Shared Options for ipsec\_server

auto - Operation	<input type="text" value="start"/>
AuthBy	<input type="text" value="secret"/>
Type of connection	<input type="text" value="tunnel"/>
DPD Action	<input type="text" value="restart"/>
DPD keepalives	<input type="text" value="60"/>
DPD Timeout	<input type="text" value="60"/>
Phase 1:IKE Encryption	<input type="text" value="3DES"/>
Phase 1:IKE Integrity	<input type="text" value="MD5"/>
Phase 1:IKE GroupType	<input type="text" value="Group2(1024)"/>
Phase1:IKE LifeTime(h)	<input type="text" value="1h"/>
Enable Perfect Forward Secrecy(PFS)	<input type="text" value="YES"/>
Phase2:ESP Encryption	<input type="text" value="3DES"/>
Phase2:ESP Integrity	<input type="text" value="MD5"/>
Phase2:ESP Keylife(h)	<input type="text" value="1h"/>
Use a Pre-Shared Key:	<input type="text" value="*****"/> 
	<input type="text" value="-- Additional Field --"/> 

**Auto – Operation** : Fine options are provided, add, ignore, manual,route,start.

**AuthBy**: there are three manners, sercret, rsasig, nerver.

**Type of connect**: There are 5 kinds of connect type, drop, passthrough, reject, transport, and tunnel.

**DPD Action**: clear, hold, restart, restart by peer.

**DPD keepalives**: The default is 60s, you can change it by yourself.

**DPD Timeout**: The timeout setting, default is 60s

### Right(Peersetting)

## IPSec Parameters

[Left\(Local Setting\)](#) | [Shared](#) | [Right\(Peer Setting\)](#)

### Right Endpoint Options for ipsec\_server

right

rightid

rightsubnets

-- Additional Field -- ▾  Add

[Save & Apply](#) [Save](#) [Reset](#) [Help](#)

**Right:** %any, means for any client is ok.

**Rightid:** the Sign of opposite side.

**Right subnets:** the opposite subnet, for example: 192.168.8.0/24

Client for IPSec settings are similar with Server for IPSec settings

## IPSec Parameters

[Left\(Local Setting\)](#) | [Shared](#) | [Right\(Peer Setting\)](#)

### Left Endpoint Options for ipsec\_client

leftid

leftsubnets

-- Additional Field -- ▾  Add

[Save & Apply](#) [Save](#) [Reset](#) [Help](#)

**Shard**

## IPSec Parameters

[Left\(Local Setting\)](#) | **Shared** | [Right\(Peer Setting\)](#)

### Shared Options for ipsec\_client

auto - Operation	<input type="text" value="start"/>
AuthBy	<input type="text" value="secret"/>
Type of connection	<input type="text" value="tunnel"/>
DPD Action	<input type="text" value="restart"/>
DPD keepalives	<input type="text" value="60"/>
DPD Timeout	<input type="text" value="60"/>
Phase 1:IKE Encryption	<input type="text" value="3DES"/>
Phase 1:IKE Integrity	<input type="text" value="MD5"/>
Phase 1:IKE GroupType	<input type="text" value="Group2(1024)"/>
Phase1:IKE LifeTime(h)	<input type="text" value="1h"/>
Enable Perfect Forward Secrecy(PFS)	<input type="text" value="YES"/>
Phase2:ESP Encryption	<input type="text" value="3DES"/>
Phase2:ESP Integrity	<input type="text" value="MD5"/>
Phase2:ESP Keylife(h)	<input type="text" value="1h"/>
Use a Pre-Shared Key:	<input type="text" value="....."/> 
	-- Additional Field -- <input type="text"/>  Add

### Right(Peer Setting)

## IPSec Parameters

[Left\(Local Setting\)](#) | **Shared** | [Right\(Peer Setting\)](#)

### Right Endpoint Options for ipsec\_server

right	<input type="text" value="%any"/>
rightid	<input type="text" value="@456"/>
rightsubnets	<input type="text" value="192.168.8.0/24"/>
	-- Additional Field -- <input type="text"/>  Add

### 3.3.4.5 OpenVPN

## OpenVPN

### OpenVPN setting

OpenVPN	<input checked="" type="radio"/> Enable <input type="radio"/> Disable
Topology	<input type="text" value="Point To Point"/>
Protocol	<input type="text" value="UDP"/>
Port	<input type="text" value="1194"/>
Device Type	<input type="text" value="TUN"/>
Peer Address	<input type="text"/>
Authentication Type	<input type="text" value="None"/>
Local Tunnel Address	<input type="text"/>
Peer Tunnel Address	<input type="text"/>
Peer Subnet Address	<input type="text"/>
Peer Subnet Mask	<input type="text"/>
Enable NAT	<input type="checkbox"/>
Enable LZO Compress	<input type="text" value="Adaptive"/>
Cipher Algorithm	<input type="text" value="Blowfish(128)"/>
MTU	<input type="text" value="1500"/>

**Topology:** Point To Point and Subnet are selectable.

**Protocol:** The protocol would be TCP or UDP.

**Port:** The port which is listened to.

**Device Type:** TUN and TAP.

**Peer Address:** The opposite side IP address.

**Authentication Type:** The Authentication type would be Static Secret and Certificate.

**Local Tunnel Address:** The ip address of local tunnel.

**Peer Tunnel Address:** the ip address of peer tunnel.

**Peer Subnet Address:** the subnet of peer address;


**Peer Subnet Mask:** the mask of peer subnet

**Enable NAT:** The NAT is enabled or not

**Enable LZO Compress:** It could be YES, NO, or Adaptive.

**Cipher Algorithm:** Blowfish(128), DES(128), 3DES(192), AES(128),AES(192), AES2 (56).

### 3.3.5 Advanced



#### 3.3.5.1 FTP Server

In this page, you can config the FTP server setting.

FTP Service  Enable  Disable  
 Resource Path  ⓘ The path of your resource  
 FTP Account  ⓘ Do not use admin or root  
 FTP Password  ⓘ  
 Anonymous Enable  ⓘ Enable Anonymous access

**FTP Service:** FTP Service is enabled by default, select “Disable” if you want to disable this function.

**Resource Path:** The path of your resource, you can select other option in the drop-down box.

**FTP Account:** The FTP account of the service, do not use admin or root

**FTP Password:** The password according to FTP Account.

#### 3.3.5.2 Dynamic DNS

Because of the allocation of dynamic IP addresses, wan IP addresses always change when the routers connect to the internet. In that case, you should use dynamic DNS. The domain name providers allows you to register a domain name which is signing up with current ip of the routers.

[Xiamen Four-Faith Communication Technology Co.,Ltd.](http://en.four-faith.com)

As a result, you can access to the latest internet IP address.

DDNS  Enable  Disable

Service Type

User Name

User Password  

Host Name

Not Use Internet IP detect

Bind Status Bind Failed

**Service Type:** F-R200 router supports several DDNS server, such as DynDNS, freedns, Zoneedit, NO-IP, 3322, easyDNS, TZO, DynSIP. User-defined server is allowed either.

**User Name:** The user name which is registered on the DDNS server. The maximum length is 64 characters.

**User Password:** The password according to the user name. The maximum length is 32 characters.

**Host Name:** The subdomain which is registered on the DDNS server. There is no limit to the length of host name.

**Not USE Internet IP detect:** The approach to access wan IP address. Router should detect the wan IP itself when it is selected.

**Bind Status:** The running state of DDNS. “Bind Failed” or “Bind success”

### 3.3.5.3 QoS Setting

QoS function controls the upload traffic and download traffic to balance the traffic, and it also can assign priority for specific IP address or MAC.

#### Basic Setup

QoS  Enable  Disable

Upload   kbps

Download   kbps

Max Upload per user   kbps

Max Download per user   kbps

Download speed(kbit/s): In order to use bandwidth management (QoS) you must enter bandwidth values for your downlink. These are generally 80% to 90% of your maximum bandwidth.

**Upload speed(kbit/s):**In order to use bandwidth management (QoS) you must enter bandwidth values for your uplink. These are generally 80% to 90% of your maximum bandwidth.

Max Upload per user:you can enter max upload bandwidth values for per user.

Max Download per user:you can enter max download bandwidth values for per user.

### 3.3.5.4 Remote Management Settings

Remote management function can manage all of the routes by the cloud platform. Users can control all devices by the cloud platform, including routine configuration, firmware upgrade and User records upload.

**Remote Server:**

Remote Server	Firmware Upgrade Settings	User Records Upload Settings
Remote Manage	<input checked="" type="radio"/> Enable <input type="radio"/> Disable	
Login Server IP	<input type="text" value="192.168.8.234"/>	
Login Server Port	<input type="text" value="9001"/>	
Heart Interval	<input type="text" value="60"/>	
3G Flow Upload Interval	<input type="text" value="600"/>	
AD Calc Upload Interval	<input type="text" value="600"/>	
Device Number	<input type="text" value="44444444"/>	
Device Phone Number	<input type="text" value="13888888888"/>	
Local Domain	<input type="text" value="wifi.cn"/>	
Device Type Description	<input type="text" value="Router"/>	
Local Auth Mode	<input type="radio"/> Login Without Authentication <input checked="" type="radio"/> Login With Authentication	
<input type="button" value="Save &amp; Apply"/> <input type="button" value="Save"/> <input type="button" value="Reset"/> <input type="button" value="Help"/>		

**Remote Manage:**

**Enable:** Enable the Remote Manage function.

**Disable:** Disable the Remote Manage function.

**Login Server IP:** The IP address of cloud platform server.

**Login Server Port:** The port of cloud platform server

**Heart Interval:** The heartbeat interval to keep connection alive., 600 seconds by default

**3G Flow Upload Interval:** The interval of 3G flow, 600 seconds by default

**Device Number:** Device number is the only identification, which is a eight-digit number. Make sure that the device number is different from other devices. The default is 44444444.

**Device Phone Number:** Enter the phone number of the sim card.

**Local Domain:** The domain name of the router.

**Device Type Description:** The type description of the device.

**Local Auth Mode:**

Login With Authentication: Enable the local authentication.  
Login Without Authentication: Disable the local authentication.

**Firmware Upgrade Settings:**

Remote Server   **Firmware Upgrade Settings**   User Records Upload Settings

Upgrade    Enable    Disable

Upgrade Server IP  

Upgrade Server Port  

**Upgrade Server IP:** The remote upgrade server IP address.  
**Upgrade Server Port:** The remote upgrade server port.  
**User Records Upload Settings:** This feature is used to upload user records.

Remote Server   Firmware Upgrade Settings   **User Records Upload Settings**

Internet Records    Enable    Disable

Server IP Address  

Server Port  

Heartbeat Interval  

**Server IP Address:** The remote user records server IP address.  
**Server Port:** The remote user records server port.

**3.3.5.5 SNMP**

Simple Network Management Protocol (SNMP) is a widely used protocol for monitoring the health and welfare of network equipment (eg. routers), computer equipment and even devices like UPSs.

## SYSTEM

Enable	Enable ▼
Location	Unknown
Contact	root
Name	four-faith

**Location:** The location of the equipment.

**Contact:** Contact this equipment management

**Name:** Device name, The default name is four-faith

## RO/RW Community

### PUBLIC

Security Name	ro
Source Address	default
Community	public

### PRIVATE

Security Name	rw
Source Address	localhost
Community	private

#### PUBLIC:

**Security Name:** The security name is RO, means only to read.

**Source Address:** The source address is default.

**Community:** The community is public by default

#### PRIVATE:

**Security Name:** The security name is rw, means read-write permissions

**Source Address:** The source address is localhost.

**Community:** The community is private by default

Click “Save & Apply” to make it effect and click “Save” just to save it but not apply, or you also can click “Reset” to turn to default value.

### 3.3.5.6 Static Routes

#### Routes

Name	Interface	Target	Netmask	Gateway	Metric	MTU
------	-----------	--------	---------	---------	--------	-----

This section contains no values yet

 Add

[Save & Apply](#) [Save](#) [Reset](#)

If you want to set static routing between the router and the other network, Click “Add” on the bottom-left corner of the page, and you will see below, then edit the rule please.

## Static Routes

Editing Rule

Name	<input type="text"/>	
Interface	<input type="text" value="WAN"/>	
Target	<input type="text"/>	 Host-IP or Network
IPv4-Netmask	<input type="text" value="255.255.255.255"/>	 if target is a network
IPv4-Gateway	<input type="text"/>	
Metric	<input type="text" value="0"/>	
MTU	<input type="text" value="1492"/>	

 Back to Overview

[Save & Apply](#) [Save](#) [Reset](#)

**Name:** Defined routing name by users, up to 25 characters

**Interface:** It indicates that users whether the Destination IP Address is on the LAN (internal wired and wireless networks) or the WAN (Internet). Select the appropriate interface option in the drop-down box.

**Target:** The destination IP address, which is the address that users want to assign a static route.

**IPv4-Netmask:** The Subnet Mask determines which portion of an IP address is the network portion, and which portion is the host portion

**IPv4-Gateway:** IP address of the gateway device that allows for contact between the router and the network or host.

**Metric:** 0-9999, the same as the ttl.

**MTU:** Maximum Transmission Unit, set the value according to the local MTU and the internet MTU, to make full use of the internet throughout.

### 3.3.5.7 GPS Setting

GPS setting allows you to set the GPS configuration. The user customized feature is provided.

GPS Setting	<input checked="" type="radio"/> Enable <input type="radio"/> Disable
Output Interface:Net	<input checked="" type="checkbox"/>
Protocol	TCP ▾
Center Address	120.42.46.98
Center Port	60001
Output Interface:Console	<input type="checkbox"/>
Update Interval	60
Speed Threshold	0
Append Device ID	<input type="checkbox"/>
User Customized	<input checked="" type="checkbox"/>
Contents:GPRMC	<input checked="" type="checkbox"/>
Contents:GPGGA	<input checked="" type="checkbox"/>
Contents:GPVTG	<input checked="" type="checkbox"/>
Contents:GPGSA	<input checked="" type="checkbox"/>
Contents:GPGSV	<input checked="" type="checkbox"/>
Contents:GPGLL	<input checked="" type="checkbox"/>

**Gps Setting:** Enable or disable GPS function.

**Output Interface:**

Net: This item selects the network output interface.

Console: This item selects the GPS serial port output interface.

**Protocol:** TCP mode or UDP mode.

**Center Address:** The GPS center's IP Address or domain name.

**Center Port:** The GPS center's listening port.

**Update Interval:** The time interval between two GPS information update, unit is second.

**Speed Threshold:** The GPS speed threshold of update gps information.

**Append Device ID:** The item selects the device ID.

**Device ID:** The device ID.

**User Customized:** GPS contents selection, including GPRMC, GPGGA, GPVTG, GPGSA, GPGSV, GPGLL.

### 3.3.5.8 Serial Setting

There is a console port on F-R200 router. Normally, this port is used to debug the router. it can also be used as a serial port. The router has embedded a serial to TCP program. The data sent to the serial port is encapsulated by TCP/IP protocol stack and then is sent to the destination server. This function can work as a DTU (Data Terminal Unit).

Serial Settings  Enable  Disable

Baudrate

Databit

Stopbit

Parity

Flow Control

Protocol

Listen Prot



**Baudrate:** The serial port's baudrate, there are several options, such as: 115200, 57600, 38400, 19200, 9600, 4800, 2400, etc.

**Databit:** The databit of the serial port

**Stopbit:** The stopbit of the serial port

**Parity:** The parity of the serial port

**Flow Control:** The flow control type of the serial port

**Protocol:** The protocol type to transmit data.

UDP(DTU) – Data transmit with UDP protocol , work as a DTU which has application protocol and hear beat mechanism.

Pure UDP – Data transmit with standard UDP protocol.

TCP(DTU) -- Data transmit with TCP protocol , work as a DTU which has application protocol and hear beat mechanism.

Pure TCP -- Data transmit with standard TCP protocol, router is the client.

TCP Server -- Data transmit with standard TCP protocol, router is the server.

TCST -- Data transmit with TCP protocol, Using a custom data

**Server Address:** The data service center’s IP Address or domain name.

**Server Port:** The data service center’s listening port.

**Device Number:** The router’s phone number.

**Device ID:** The router’s identity ID.

**Heartbeat Interval:** The time interval to send heart beat packet. This item is valid only when you choose UDP(DTU) or TCP(DTU) protocol type.


**Listen Port:** This item is valid when Protocol Type is “TCP Server”

**Custom Heartbeat Packet :** This item is valid when Protocol Type is “TCST”

**Custom Registration Packets:** This item is valid when Protocol Type is “TCST”

### 3.3.6 Management

The Management screen allows you to change the system settings of the F-R200 router. On this page you will find most of the configurable items of the router.



#### 3.3.6.1 Admin Password

In this part, user can modify the password and submit it to make it effect.

### Change the password of the system administrator (User admin)

Password	<input type="password"/>	
Confirmation	<input type="password"/>	

The new password must not exceed 32 characters in length and must not include any spaces. Enter the new password a second time to confirm it.

**Note:**

Default username is admin.

It is strongly recommended that you change the factory default password of the router, which is admin. All users who try to access the router's web-based utility or Setup Wizard will be prompted for the router's password.

### 3.3.6.2 System Log Setting

System Log Setting is used to modify the system log configuration.

Log File Path	<input type="text" value="System Memory"/>	
Log Buffer Size	<input type="text" value="16"/>	 kiB
External Log Server	<input type="text" value="0.0.0.0"/>	
External Log Server Port	<input type="text" value="514"/>	
Log output level	<input type="text" value="Debug"/>	

**Log File Path:** Select the storage path in the drop-down box, which are “System memory”, “Console”, “KINGSTON(mmcblk0p1:),” “Volume(sda1:),” Please be attention that system log would be lost when the system is power failures if “System memory” is selected.

**Log Buffer Size:** Enter the buffer length of log file, in KB. The Log file will be clean when the data length is over the threshold you have defined.

**External Log Server:** If you have an external log server, enter the IP address.

**Log output level:** Select the debug level in the drop-down box. The debug levels contain Debug,

Info, Notice, Warning, Error, Critical, Alert, Emergency. Debug is the lowest priority level while “Emergency” is the highest. Select the appropriate level. The lower the priority is, the more output. Click the “Save & Apply” to make it effect.

### 3.3.6.3 Backup/Restore

Backup/Restore functions, as the name, is used to backup the current configurations, and restore the settings at anytime if necessary.

#### Backup / Restore

---

Here you can backup and restore your router configuration and - if possible - reset the router to the default settings.

- [Create backup](#)

---

- [Reset router to defaults](#)

---

- Import Backup Archive

Backup Archive:

No file chosen

**create backup:** In case you need to reset the router back to the factory default settings, click “Create backup” to backup the current configurations, which maybe take several minutes. Some of configuration files, which are under the directory /lib and /etc, are compressed to backup-Four-Faith-xxxx-xx-xx.tar.gz.

**Reset router to defaults:** It is used to reset all configurations to their default values.

**Note:**

Any settings you have saved will be lost when the default settings are restored. After restoring, the router is accessible under the default IP address 192.168.4.1 and the default password is “admin”.

### 3.3.6.4 Flash Firmware

#### Flash Firmware

---

Upload an OpenWrt image file to reflash the device.

Firmware image:

No file chosen

**Flash Firmware:** New firmware versions are posted at [www.four-faith.com](http://www.four-faith.com) and can be downloaded. If the Router is not experiencing difficulties, then there is no need to download a recent firmware version, unless that version has a new feature that you want to use.

**Note:**

When you upgrade the Router's firmware, you lose its configuration settings, so make sure that you have backup the current router settings before you upgrade the firmware.

**To upgrade the Router's firmware:**

1. Download the firmware upgrade file from the website.
2. Click the Browse... button and chose the firmware upgrade file.
3. Click the “Upgrade Image” button and wait until the upgrade is finished.

**Note:**

Upgrading firmware may take a few minutes.  
Do not turn off the power or press the reset button!

**After flashing, reset to:** If you want to reset the router to the default settings for the firmware version you are upgrading to, click the Firmware Defaults option.

### 3.3.6.5 Sys Log


**Sys Log** shows the system log information to user . You can get the system running state of the router, and diagnose system problems.

```
Dec 29 14:14:39 wan_monitor[603]: get_ipaddr_state fails
Dec 29 14:14:41 syslog: invalid param
Dec 29 14:14:46 syslog: invalid param
Dec 29 14:14:49 wan_monitor[603]: get_ipaddr_state fails
Dec 29 14:14:51 syslog: invalid param
Dec 29 14:14:56 syslog: invalid param
Dec 29 14:14:59 wan_monitor[603]: get_ipaddr_state fails
Dec 29 14:15:01 syslog: invalid param
Dec 29 14:15:06 syslog: invalid param
Dec 29 14:15:09 wan_monitor[603]: get_ipaddr_state fails
Dec 29 14:15:11 syslog: invalid param
Dec 29 14:15:16 syslog: invalid param
Dec 29 14:15:16 syslog: remote_mgr_v2: connect to choose login svr retry max, break!
Dec 29 14:15:16 syslog: remote_mgr_v2: choose server fail!
Dec 29 14:15:19 wan_monitor[603]: get_ipaddr_state fails
Dec 29 14:15:21 syslog: invalid param
Dec 29 14:15:26 sys_monitor[26609]: nginx is dead, so start it again
Dec 29 14:15:26 sys_monitor[26609]: php-fcgi is dead, so start it again
Dec 29 14:15:30 wan_monitor[603]: get_ipaddr_state fails
Dec 29 14:15:40 wan_monitor[603]: get_ipaddr_state fails
Dec 29 14:15:41 syslog: wdown_app: find version un-equal, do upgrade...
Dec 29 14:15:44 syslog: invalid param
Dec 29 14:15:49 syslog: invalid param
Dec 29 14:15:50 wan_monitor[603]: get_ipaddr_state fails
Dec 29 14:15:54 syslog: invalid param
Dec 29 14:15:56 syslog: remote_mgr_v2: connect to choose login svr retry max, break!
Dec 29 14:15:56 syslog: remote_mgr_v2: choose server fail!
Dec 29 14:15:59 syslog: invalid param
```

### 3.3.6.6 Attached Setting

**Attached Setting** functions to show the attached devices in the tables, Which shows the “IP Address”, “Mac”, “Hostname”. Click “Refresh” to update the attached device table information.

IP Address	MAC	Hostname
------------	-----	----------



### 3.3.6.7 Time Setting

This function allows you to setting the system time.

## Set System Time

Current system time 2016-07-27 16:39:14

System Time Type  ntp  rtc

NTP Time Server

Port

Update Interval   seconds

Timezone

Daylight



**Current system time:** Show the current system time.

**System Time Type:** The optional time type of the system are RTC and NTP. If RTC selected, the hardware RTC time is used. If ntp selected, it can synchronize to the **NTP time server:** As shown, The current time type is ntp.

**NTP Time Server:** Select the optional time server which you want to synchronize to. You also can select the custom option, and enter the time server by yourself.

**Port:** The listening port of the time server.

**Update Interval:** It specifies the interval of NTP time updating.

**Timezone:** Users should select the proper timezone according to longitude and latitude.

**Daylight:** It specifies the daylight time according to the longitude and latitude.

Current system time 2015-12-29 14:19:28

System Time Type  ntp  rtc

Current RTC Time 2139-03-14 21:16:14

RTC Date   eg: 2015-01-01

RTC Time   eg: 12:00:00

[Save & Apply](#) [Save](#) [Reset](#) [Help](#)

If the RTC is selected, the RTC clock time is shown as above.

RTC Date: Enter the RTC date into the field if you want to modify it. Please pay attention to the date format, separated with “-”;

RTC Time: Enter the RTC date into the field if you want to modify it. Please pay attention to the date format, separated with “:”;

### 3.3.6.8 Reboot

This feature is used to reboot the operating system of your device. Click the “Perform reboot” as below.

**Warning: There are unsaved changes that will be lost while rebooting!**

[Perform reboot](#)


### 3.3.6.9 Logout

This function allows you to logout from the web GUI, and turn to the login page.

### 3.3.7 Appendix

The following steps describe how to setup Windows XP Hyper Terminal.

Press “Start”→”Programs”→”Accessories”→”Communications”→”Hyper Terminal”



Input connection name, choose “OK”

Choose the correct COM port which connects to modem, choose “OK”



Configure the serial port parameters as following, choose “OK”


Bits per second: 115200

Data bits: 8

Parity: None

Stop bits: 1

Flow control: None



Complete Hyper Terminal operation, It runs as following

