

| | |
|----------------------------|----------------------|
| Document Title | GV350CEU User Manual |
| Version | 1.06 |
| Date | 2025-02-21 |
| Status | Release |
| Document Control ID | TRACGV350CEUUM006 |

General Notes

Queclink offers this information as a service to its customers, to support application and engineering efforts that use the products designed by Queclink. The information provided is based upon requirements specifically provided to Queclink by the customers. Queclink has not undertaken any independent search for additional relevant information, including any information that may be in the customer's possession. Furthermore, system validation of this product designed by Queclink within a larger electronic system remains the responsibility of the customer or the customer's system integrator. All specifications supplied herein are subject to change.

Copyright

This document contains proprietary technical information which is the property of Queclink Wireless Solutions Co., Ltd. The copying of this document, distribution to others, and communication of the contents thereof, are forbidden without express authority. Offenders are liable to the payment of damages. All rights reserved in the event of grant of a patent or the registration of a utility model or design. All specifications supplied herein are subject to change without notice at any time.

Contents

| | |
|---|----|
| Contents | 2 |
| Table Index | 3 |
| Figure Index | 4 |
| 0. Revision History | 5 |
| 1. Introduction | 6 |
| 1.1. Reference | 6 |
| 1.2. Terms and Abbreviations | 6 |
| 2. Product Overview | 7 |
| 2.1. Check Parts List | 7 |
| 2.2. Parts List | 8 |
| 2.3. Interface Definition | 9 |
| 2.4. Wiring Scheme | 10 |
| 3. Get Started | 11 |
| 3.1. Open the Case | 11 |
| 3.2. Close the Case | 11 |
| 3.3. Install a SIM Card | 12 |
| 3.4. Install the Internal Backup Battery | 13 |
| 3.5. Power Connection | 14 |
| 3.6. Power On | 14 |
| 3.7. Ignition Detection | 15 |
| 3.8. Digital Inputs | 16 |
| 3.9. Analog Inputs | 17 |
| 3.10. Digital Outputs | 18 |
| 3.11. Device Status LED | 20 |
| 3.12. Serial Port/UART Interface | 21 |
| 3.13. 1-WIRE Interface | 22 |
| 3.14. Motion Sensor Direction | 23 |
| 4. CAN Installation | 24 |
| 4.1. CAN Interface | 24 |
| 4.2. Installation Diagram | 25 |
| 4.2.1. General Connection Diagram for Passenger Cars | 25 |
| 4.2.2. Connection Diagram for Trucks with J1939 (CAN-bus) and J1708 | 26 |
| 4.2.3. Connection Diagram of FMS Connector for Trucks | 27 |
| 4.2.4. Connection Diagram for J1708-Based Trucks | 28 |
| 4.3. CAN-bus Synchronization | 28 |
| 4.4. Firmware Upgrade | 28 |

Table Index

| | |
|---|----|
| Table 1. GV350CEU Protocol Reference | 6 |
| Table 2. Terms and Abbreviations | 6 |
| Table 3. Parts List..... | 8 |
| Table 4. Description of 22 PIN Connections | 9 |
| Table 5. Electrical Characteristics of Ignition Detection | 15 |
| Table 6. Electrical Characteristics of Digital Inputs..... | 16 |
| Table 7. Electrical Characteristics of Digital Outputs..... | 18 |
| Table 8. Definition of Device Status and LED | 20 |

Figure Index

| | |
|---|----|
| Figure 1. Appearance of GV350CEU | 7 |
| Figure 2. 22-PIN Connector on GV350CEU..... | 9 |
| Figure 3. Open the Case | 11 |
| Figure 4. Close the Case | 11 |
| Figure 5. SIM Card Installation | 12 |
| Figure 6. Backup Battery Installation | 13 |
| Figure 7. Typical Power Connection | 14 |
| Figure 8. Typical Ignition Detection..... | 15 |
| Figure 9. Typical Digital Input Connection..... | 16 |
| Figure 10. Typical Analog Input Connection..... | 17 |
| Figure 11. Digital Output Internal Drive Circuit..... | 18 |
| Figure 12. Typical Connection with Relay..... | 18 |
| Figure 13. Typical Connection with LED | 19 |
| Figure 14. GV350CEU LED on the Case | 20 |
| Figure 15. Typical Connection with RS232 Port..... | 21 |
| Figure 16. 1-WIRE Interface | 22 |
| Figure 17. Motion Sensor Direction | 23 |
| Figure 18. CAN Interface | 24 |
| Figure 19. For Passenger Cars | 25 |
| Figure 20. For Trucks with J1939 (CAN-bus) and J1708..... | 26 |
| Figure 21. FMS Connector for Trucks | 27 |
| Figure 22. For J1708-Based Trucks | 28 |

0. Revision History

| Version | Date | Author | Description of Change |
|---------|------------|-------------|---|
| 1.00 | 2021-09-28 | Willie Liu | 1. Initial. |
| 1.01 | 2023-07-14 | Forrest Cao | 1. Added note for using 1-WIRE. |
| 1.02 | 2023-11-09 | Elvin Shen | 1. Added description for CAN LED status. |
| 1.03 | 2023-12-20 | Willie Liu | 1. Added some notes for using 1-WIRE. |
| 1.04 | 2024-02-23 | Willie Liu | 1. Added the wiring scheme. |
| 1.05 | 2024-05-23 | Willie Liu | 1. Modified the terms and abbreviations in chapter 1.2. |
| 1.06 | 2025-02-21 | Rita Pan | 1. Modified wiring scheme. |

1. Introduction

The GV350CEU is a compact GNSS tracker designed for a wide variety of vehicle tracking applications. It has multiple I/O interfaces that can be used for monitoring or controlling external devices. Its built-in GNSS receiver has superior sensitivity and fast time to first fix. Its six-band LTE-FDD in Europe and GSM/GPRS 850/900/1800/1900 MHz allowing the GV350CEU's location to be monitored in real time or periodically tracked by a backend server and mobile devices. Its built-in 3-axis accelerometer allows driving behaviour monitoring, motion detection and extended battery life through sophisticated power management algorithms. It also has built-in CAN Module. System integration is straightforward as complete documentation is provided for the full featured @Track protocol. The @Track protocol supports a wide variety of reports including emergency, geo-fence boundary crossings, driving behaviour, low battery and scheduled GNSS position.

1.1. Reference

Table 1. GV350CEU Protocol Reference

| SN | Document Name | Remark |
|-----|--|---|
| [1] | GV350CEU @Track Air Interface Protocol | The air protocol interface between GV350CEU and backend server. |

1.2. Terms and Abbreviations

Table 2. Terms and Abbreviations

| Abbreviation | Description |
|--------------|----------------------------------|
| AIN | Analog Input |
| IGN | Ignition input, positive trigger |
| /IN | Digital input, negative trigger |
| DATA-1W | Data for one wire |
| VDD-1W | VDD for one wire |
| PWR | External DC power input |
| OUT | Digital Output |
| GND | Power and digital ground |
| RXD | Receive Data |
| TXD | Transmit Data |

2. Product Overview

2.1. Check Parts List

Before starting, check whether all the following items have been included with your GV350CEU. If anything is missing, please contact the supplier.







Figure 1. Appearance of GV350CEU

2.2. Parts List

Table 3. Parts List

| Name | Picture |
|---------------------------------------|--|
| GV350CEU Locator | 94*58.5*21 mm |
| User Cable |  |
| DATA_CABLE_W (Optional) |  |
| Power Protection Cable_Kit (Optional) |  |

2.3. Interface Definition

The GV350CEU has a 22 PIN interface connector which contains the connections for power, I/O, RS232, etc. The sequence and definition of the 22-PIN connector are shown in the following figure:
















Figure 2. 22-PIN Connector on GV350CEU

Table 4. Description of 22 PIN Connections

| Description | PIN Name | PIN No | Cable | PIN No | PIN Name | Description |
|--|----------|--------|---|--------|----------|----------------------------------|
| VDD for one wire | VDD_1W | 11 |  | 22 | CAN2L | CAN 2 negative |
| Data for one wire | DATA_1W | 10 |  | 21 | CAN2H | CAN 2 positive |
| External DC power input, 8-32V | VIN | 9 |  | 20 | CAN1H | CAN 1 positive |
| Digital input, negative trigger | /IN1 | 8 |  | 19 | CAN1L | CAN 1 negative |
| Digital input, negative trigger | /IN2 | 7 |  | 18 | GND | Power and digital ground |
| Digital output | OUT4 | 6 |  | 17 | OUT2 | Digital output |
| Digital output | OUT5 | 5 |  | 16 | IGN | Ignition input, positive trigger |
| Digital output | OUT3 | 4 |  | 15 | RXD | UART RXD, RS232 |
| Digital output, Open drain, 150 mA max, with latch circuit | OUT1 | 3 |  | 14 | TXD | UART TXD, RS232 |
| Analog input (0-16V) | ADIN1 | 2 |  | 13 | /IN3 | Digital input, Negative trigger |
| Analog input (0-30V) | ADC_IN | 1 |  | 12 | ADIN2 | Analog input (0-16V) |

2.4. Wiring Scheme



3. Get Started

3.1. Open the Case



Figure 3. Open the Case

Remove the screws on the four corners with the screwdriver to open the device.

3.2. Close the Case



Figure 4. Close the Case

Tighten the screws on the four corners with the screwdriver to close the device.

3.3. Install a SIM Card

Open the case and ensure the unit is not powered. Slide the holder right to open the SIM card holder. Insert the SIM card into the holder as shown below with the gold-colored contact area facing down. Take care to align the cut mark. Close the SIM card holder. Close the case.



Figure 5. SIM Card Installation

3.4. Install the Internal Backup Battery



Figure 6. Backup Battery Installation

GV350CEU has an internal backup Li-ion battery.

3.5. Power Connection

PWR (PIN9)/GND (PIN18) are the power input pins. The input voltage range for this device is from 8V to 32V. The device is designed to be installed in common vehicles that operate on 12V or 24V systems without the need for external transformers. But it is recommended to use Power Protection Cable Kit if it is installed in a truck with 24V battery.



Figure 7. Typical Power Connection

3.6. Power On

Please pay attention to the following situations when powering on the device:

1. Backup battery is connected to the device:

- The device can be powered on when the USB cable is connected.
- The device can be powered on when the external power supply is connected.

2. Backup battery is not connected to the device:

- The device cannot be powered on when the USB cable is connected only.
- The device can be powered on when the external power supply is connected only.

3.7. Ignition Detection

Table 5. Electrical Characteristics of Ignition Detection

| Logical Status | Electrical Characteristics |
|----------------|----------------------------|
| Active | 5.0V to 32V |
| Inactive | 0V to 3V or open |




Figure 8. Typical Ignition Detection

IGN (Pin16) is used for ignition detection. It is strongly recommended to connect this pin to ignition key "RUN" position as shown above.

An alternative to connecting to the ignition switch is to find a non-permanent power source that is only available when the vehicle is running, for example, the power source for the FM radio.

IGN signal can be configured to start transmitting information to the backend server when ignition is on, and enter the power saving mode when ignition is off.

3.8. Digital Inputs

There are three general purpose digital inputs on GV350CEU. They are all negative triggers.

Table 6. Electrical Characteristics of Digital Inputs

| Logical Status | Electrical Characteristics |
|----------------|----------------------------|
| Active | 0V to 0.6V |
| Inactive | Open |

The following figure shows the recommended connection of a digital input.




Figure 9. Typical Digital Input Connection

3.9. Analog Inputs

There are three analog inputs on GV350CEU, and the analog input voltage ranges are 0-16V and 0-30V. The following figure shows the recommended connection.



Figure 10. Typical Analog Input Connection

Note:

1. For PIN 12 and PIN2, the voltage range is 0-16V.
2. For PIN 1, the voltage range is 0-30V.

3.10. Digital Outputs

There are five digital outputs on GV350CEU. All five digital outputs are of open drain type and the maximum drain current is 150mA. Each output has the built-in over current PTC resettable fuse.




Figure 11. Digital Output Internal Drive Circuit

Table 7. Electrical Characteristics of Digital Outputs

| Logical Status | Electrical Characteristics |
|----------------|----------------------------|
| Enable | <1.5V @150 mA |
| Disable | Open drain |




Figure 12. Typical Connection with Relay




Figure 13. Typical Connection with LED

Note:

1. OUT1 will latch the output state during reset.
2. Many modern relays come with a flyback diode pre-installed internal to the relay itself. If the relay has this diode, please ensure the relay polarity is properly connected. If this diode is not internal, it should be added externally. A common diode such as a 1N4004 will work in most circumstances.

3.11. Device Status LED



Figure 14. GV350CEU LED on the Case

Table 8. Definition of Device Status and LED

| LED | Device Status | LED Status |
|------|--|--|
| CAN | Operating mode, CAN-bus or J1708 active (only one of those) | The green LED blinks once every second. |
| | Operating mode, CAN-bus(es) and J1708 sleep or disabled | The green LED blinks once every 4 seconds. |
| | Operating mode, two buses active (2 CAN-buses, or CAN-bus and J1708) | The green LED blinks twice every second. |
| | Low power mode (sleep) | OFF |
| | CAN-bus codes synchronization | The red LED blinks quickly (ca. 7 times per second). |
| | CAN-bus codes synchronization finished successfully. | Green ON (after synchronization) |
| | CAN-bus codes synchronization failed (CAN-bus wires are properly connected, but codes have not been recognized). | Red ON (after synchronization) |
| | CAN-bus codes synchronization failed (no CAN-bus connection or CAN-bus sleep). | The red LED blinks 0.5s. The green LED blinks 0.5s. |
| | Invalid configuration (e.g. vehicle not synchronized) | The red LED blinks once every 2 seconds. |
| | The device failed to power on. Return the device to the producer for diagnosis. | Red ON (after power-on) |
| GNSS | GNSS chip is powered off. | OFF |
| | GNSS sends no data or data format error occurs. | Slow flashing |
| | GNSS chip is searching GNSS information. | Fast flashing |
| | GNSS chip has gotten GNSS information. | ON |

| | | |
|-----|---|---------------|
| CEL | The device is searching network. | Fast flashing |
| | The device has been registered on the network. | Slow flashing |
| | The SIM card needs PIN code to unlock. | ON |
| PWR | No external power and internal battery voltage is lower than 3.6V. | OFF |
| | No external power and internal battery voltage is below 3.7V. | Slow flashing |
| | The external power supply has been connected to the device and the internal battery of the device is charging. | Fast flashing |
| | The external power supply has been connected to the device and the internal battery of the device is fully charged. | ON |

Note:

1. CEL LED, GNSS LED and PWR LED lights can be configured to be turned off after a period time by using the configuration tool.
2. Fast flashing: For CEL LED, it is about 60 Ms ON/780 Ms OFF. For GNSS LED and PWR LED, it is about 100 Ms ON/100 Ms OFF.
3. Slow flashing: For CEL LED, it is about 60 Ms ON/1940 Ms OFF. For GNSS LED and PWR LED, it is about 600 Ms ON/600 Ms OFF.

3.12. Serial Port/UART Interface

There are two lines dedicated to the Serial Port/UART interface (TXD and RXD). TXD/RXD is standard RS232 signal.




Figure 15. Typical Connection with RS232 Port

3.13. 1-WIRE Interface


There are two lines dedicated to the 1-WIRE, one is VDD-1-WIRE and the other is DATA-1-WIRE. The following diagram shows the recommended connection of 1-wire device.




Figure 16. 1-WIRE Interface

Note:

1. Before connecting and removing accessories, please power off the device first.
2. Please keep the voltage on the VDD-1-WIRE and DATA-1-WIRE to **no more than 5.5V** when using 1-WIRE.
3. Avoid short circuits in VIN (or high voltage signal cable), GND and VDD_1_WIRE/DATA signal cables. Short circuits may damage the 1-WIRE chip and cause device abnormality.
4. When the 1-WIRE function is not used, please wrap the VDD_1_WIRE/DATA signal cable with insulation tape to avoid contact with other high-voltage signal cables or GND.



5. When using 1-WIRE, please wrap the VDD_1_WIRE/DATA connection with insulation tape.



3.14. Motion Sensor Direction

GV350CEU has an internal 6-axis gyroscope sensor supporting driving behavior monitoring, crash detection and motion detection. The following shows the directions of the motion sensor:



Figure 17. Motion Sensor Direction

Note:

1. The opposite direction of the cable harness is the positive direction of the X-axis.
2. The Z-axis is in positive direction above the label surface.
3. The positive directions of the three axes are perpendicular to each other, as shown in the figure.

4. CAN Installation

4.1. CAN Interface

There are two CAN interfaces, CAN2L/CAN2H, CAN1L/CAN1H. And CAN2 can also be connected to the J1708 interface of the vehicle.



Figure 18. CAN Interface

4.2. Installation Diagram

4.2.1. General Connection Diagram for Passenger Cars

Generally, CAN1 and CAN2 interfaces in GV350CEU can be connected to a passenger car's CAN-bus interface and OBD interface, as shown below.




Figure 19. For Passenger Cars

Note:

There is an installation manual for every supported car model. It is crucial to connect CAN1 wires to particular vehicle's CAN-bus. Connecting to invalid CAN-bus may result in partial or total loss of logistic data.

When, due to installation manual of particular car model, CAN1 is to be connected to OBD pins 6&14, connection of CAN2 shall be void.

4.2.2. Connection Diagram for Trucks with J1939 (CAN-bus) and J1708

Generally, J1939 can be connected to CAN1 of GV350CEU, and J1708 can be connected to CAN2 of GV350CEU, as shown below.




Figure 20. For Trucks with J1939 (CAN-bus) and J1708

Note:

For connection places of CAN and J1708 for particular truck model, please refer to installation manual for particular truck model.

4.2.3. Connection Diagram of FMS Connector for Trucks

Generally, the FMS connector can be connected to CAN1 of GV350CEU.

FMS connector shape and pinout may vary between truck makes and models. The picture is illustrative. For CAN1 connection position, please refer to the installation manual for the particular truck model.




Figure 21. FMS Connector for Trucks

4.2.4. Connection Diagram for J1708-Based Trucks

GV350CEU connects to J1708 based trucks only through CAN2.




Figure 22. For J1708-Based Trucks

4.3. CAN-bus Synchronization

CAN-bus codes synchronization function allows GV350CEU to detect the vehicle model to which the GV350CEU is connected. Switch vehicle ignition on and send the command **AT+GTRTO=gv350ceu,22,2,,,,,FFFF\$** after GV350CEU is installed in the vehicle, and then the synchronization will start. During synchronization, the flashing of the can lamp can be observed. For details, please refer to the commands **AT+GTRTO-22** and **AT+GTRTO-2F**.

4.4. Firmware Upgrade

A file with the firmware / configuration is supplied by the manufacturer. CAN firmware upgrade or CAN configuration upgrade can be set through **AT+GTCFU** or **AT+GTUPD**. For details, please refer to the command **AT+GTCFU** or the document [GV350CEU @Track Air Interface Protocol](#).