

GL33CG Quick Start

Page 1: Basic Operation

1

Check Parts List



The Micro_USB is not in the delivery list. Please contact your vendor for it.

2


Check Appearance

Please refer to Page 2 for details.



3

Install a SIM Card



SIM Card

4


Turn on GL33CG



Long press for 3s to turn on the device.


5

Find Queclink_Driver_AsrV2.0.1.0.zip in develop suit and install the driver. If you have already installed it, please go to Step 6.




6

Connect GL33CG to computer using Micro USB.



7

Find "Queclink @Track MT Setup Vx.x.x.exe" in develop suit and run it to configure the running parameters of GL33CG.



8


Please fully charge the battery before using GL33CG for the first time.



Page 2: PC Manage Tool Quick Start


1

If the driver is already installed, MT will recognize it automatically. Then click **Configure**.




2

If you want to test the GL33CG by SMS. Then set **“Report Mode”** to **“SMS”** and input the phone number which you want to receive the SMS from GL33CG. After that you can go to **Step 6**.




3

Set **“Report Mode”** to **“TCP Short Connection”**. Input the IP address and port number of the backend server. Please make sure the IP address can be accessed by Internet and the data sent to this address can be received.



4

Please contact your SIM card provider and get the APN information for GPRS. Input it in **AT+GTBSI** setting.



5

Click the **“Send”** button and update the parameters of GL33CG. Then GL33CG can report information to your backend server or SMS receiver.
Note: These commands can also be sent to GL33CG by SMS.

AT+GTBSI=gl33cg,,,,,,0,,,FFFF\$

Command has been accepted when you see the window below.

Queclink @Track MT




Save settings successfully

OK


6

Set the parameters of fixed time report so that GL33CG will report its position to backend server periodically. Click **“Send”** button to update the parameters.
The following screenshot shows how to configure GL33CG to report its position every 3 minutes.



7

The following screenshot shows how to create a Geo-Fence rule. Click **“Send”** button to update the parameters.



After these steps, GL33CG will have some basic tracking functions like fixed time report and Geo-Fence. For other advanced functions of GL33CG, please refer to **GL33CG @Track Air Interface Protocol** or visit our website.

<http://www.queclink.com>
sales@queclink.com