

Document Title	GV305CEU User Manual
Version	1.03
Date	2025-02-21
Status	Release
Document Control ID	TRACGV305CEUUM003

General Notes

Queclink offers this information as a service to its customers, to support application and engineering efforts that use the products designed by Queclink. The information provided is based upon requirements specifically provided to Queclink by the customers. Queclink has not undertaken any independent search for additional relevant information, including any information that may be in the customer's possession. Furthermore, system validation of this product designed by Queclink within a larger electronic system remains the responsibility of the customer or the customer's system integrator. All specifications supplied herein are subject to change.

Copyright

This document contains proprietary technical information which is the property of Queclink Wireless Solutions Co., Ltd. The copying of this document, distribution to others, and communication of the contents thereof, are forbidden without express authority. Offenders are liable to the payment of damages. All rights reserved in the event of grant of a patent or the registration of a utility model or design. All specifications supplied herein are subject to change without notice at any time.

Contents

Contents	2
Table Index	3
Figure Index.....	4
0. Revision History.....	5
1. Introduction	6
1.1. Reference.....	6
1.2. Terms and Abbreviations	6
2. Product Overview.....	6
2.1. Check Parts List.....	7
2.2. Parts List	8
2.3. Interface Definition	9
2.4. Wiring Scheme	10
3. Get Started	11
3.1. Open the Case	11
3.2. Close the Case	11
3.3. Install a SIM Card.....	12
3.4. Install the Internal Backup Battery.....	13
3.5. Power Connection	14
3.6. Power On.....	14
3.7. Ignition Detection.....	15
3.8. Digital Inputs	16
3.9. Analog Inputs	17
3.10. Digital Outputs	18
3.11. Device Status LED	20
3.12. Serial Port/UART Interface	21
3.13. 1-WIRE Interface.....	22
3.14. Motion Sensor Direction	23
3.15. RS485 Interface	24

Table Index

Table 1. GV305CEU Protocol Reference	6
Table 2. Terms and Abbreviations	6
Table 3. Parts List.....	8
Table 4. Description of 22 PIN Connections	9
Table 5. Electrical Characteristics of Ignition Detection	15
Table 6. Electrical Characteristics of Digital Inputs.....	16
Table 7. Electrical Characteristics of Digital Outputs.....	18
Table 8. Definition of Device Status and LED	20

Figure Index

Figure 1. Appearance of GV305CEU	7
Figure 2. The 22 PIN Connector on the GV305CEU.....	9
Figure 3. Open the Case	11
Figure 4. Close the Case	11
Figure 5. SIM Card Installation	12
Figure 6. Backup Battery Installation	13
Figure 7. Typical Power Connection	14
Figure 8. Typical Ignition Detection.....	15
Figure 9. Typical Digital Input Connection.....	16
Figure 10. Typical Analog Input Connection.....	17
Figure 11. Digital Output Internal Drive Circuit.....	18
Figure 12. Typical Connection with Relay.....	18
Figure 13. Typical Connection with LED	19
Figure 14. GV305CEU LED on the Case	20
Figure 15. Typical Connection with RS232 Port.....	21
Figure 16. 1-Wire Interface	22
Figure 17. Motion Sensor Direction	23
Figure 18. RS485 Interface	24

0. Revision History

Version	Date	Author	Description of Change
1.00	2022-03-08	Willie Liu	1. Initial
1.01	2023-10-31	Willie Liu	1. Modified the description of the LED light status of the device.
1.02	2024-02-23	Willie Liu	1. Added the wiring scheme.
1.03	2025-02-21	Rita Pan	1. Modified wiring scheme.

1. Introduction

The GV305CEU is a compact GNSS tracker designed for a wide variety of vehicle tracking applications. It has multiple I/O interfaces that can be used for monitoring or controlling external devices. Its built-in GNSS receiver has superior sensitivity and fast time to first fix. Its six-band LTE-FDD in Europe and GSM/GPRS 850/900/1800/1900 MHz allowing the GV305CEU's location to be monitored in real time or periodically tracked by a backend server and mobile devices. Its built-in 3-axis accelerometer allows driving behaviour monitoring, motion detection and extended battery life through sophisticated power management algorithms. The @Track protocol supports a wide variety of reports including emergency, geo-fence boundary crossings, driving behaviour, low battery and scheduled GNSS position.

1.1. Reference

Table 1. GV305CEU Protocol Reference

SN	Document Name	Remark
[1]	GV305CEU @Track Air Interface Protocol	The air protocol interface between GV305CEU and backend server.

1.2. Terms and Abbreviations

Table 2. Terms and Abbreviations

Abbreviation	Description
AIN	Analog Input
IGN	Ignition input, positive trigger
/IN	Digital input, negative trigger
DATA-1W	Data for one wire
VDD-1W	VDD for one wire
PWR	External DC power input
OUT	Digital Output
GND	Power and digital ground
RXD	Receive Data
TXD	Transmit Data
485A	RS485 positive
485B	RS485 negative

2. Product Overview

2.1. Check Parts List

Before starting, check whether all the following items have been included with your GV305CEU. If anything is missing, please contact the supplier.







Figure 1. Appearance of GV305CEU

2.2. Parts List

Table 3. Parts List

Name	Picture
GV305CEU Locator	94*58.5*21 mm
User Cable	
DATA_CABLE_W (Optional)	
Power Protection Cable_Kit (Optional)	

2.3. Interface Definition

The GV305CEU has a 22 PIN interface connector which contains the connections for power, I/O, RS232, etc. The sequence and definition of the 22-PIN connector are shown in the following figure:
















Figure 2. The 22 PIN Connector on the GV305CEU

Table 4. Description of 22 PIN Connections

Description	PIN Name	PIN No	Cable	PIN No	PIN Name	Description
VDD for one wire	VDD_1W	11		22	/IN4	Digital input
Data for one wire	DATA_1W	10		21	OUT6	Digital output
External DC power input, 8-32V	VIN	9		20	485A	RS485 positive
Digital input, negative trigger	/IN1	8		19	485B	RS485 negative
Digital input, negative trigger	/IN2	7		18	GND	Power and digital ground
Digital output	OUT4	6		17	OUT2	Digital output
Digital output	OUT5	5		16	IGN	Ignition input, positive trigger
Digital output	OUT3	4		15	RXD	UART RXD, RS232
Digital output, Open drain, 150 mA max, with latch circuit	OUT1	3		14	TXD	UART TXD, RS232
Analog input (0-16V)	ADIN1	2		13	/IN3	Digital input, Negative trigger
Analog input (0-30V)	ADC_IN	1		12	ADIN2	Analog input (0-16V)

2.4. Wiring Scheme



3. Get Started

3.1. Open the Case



Figure 3. Open the Case

Remove the screws on the four corners with the screwdriver to open the device.

3.2. Close the Case



Figure 4. Close the Case

Tighten the screws on the four corners with the screwdriver to close the device.

3.3. Install a SIM Card

Open the case and ensure the unit is not powered. Slide the holder right to open the SIM card holder. Insert the SIM card into the holder as shown below with the gold-colored contact area facing down. Take care to align the cut mark. Close the SIM card holder. Close the case.




Figure 5. SIM Card Installation

3.4. Install the Internal Backup Battery



Figure 6. Backup Battery Installation

GV305CEU has an internal backup Li-ion battery.

3.5. Power Connection

PWR (PIN9)/GND (PIN18) are the power input pin. The input voltage range for this device is from 8V to 32V. The device is designed to be installed in common vehicles that operate on 12V or 24V systems without the need for external transformers. But it is recommended to use Power Protection Cable Kit if it is installed in a truck with 24V battery.



Figure 7. Typical Power Connection

3.6. Power On

Please pay attention to the following situations when powering on the device:

1. Backup battery is connected to the device:

- The device can be powered on when the USB cable is connected.
- The device can be powered on when the external power supply is connected.

2. Backup battery is not connected to the device:

- The device cannot be powered on when the USB cable is connected only.
- The device can be powered on when the external power supply is connected only.

3.7. Ignition Detection

Table 5. Electrical Characteristics of Ignition Detection

Logical Status	Electrical Characteristics
Active	5.0V to 32V
Inactive	0V to 3V or open




Figure 8. Typical Ignition Detection

IGN (Pin16) is used for ignition detection. It is strongly recommended to connect this pin to ignition key "RUN" position as shown above.

An alternative to connecting to the ignition switch is to find a non-permanent power source that is only available when the vehicle is running, for example, the power source for the FM radio.

IGN signal can be configured to start transmitting information to the backend server when ignition is on, and enter the power saving mode when ignition is off.

3.8. Digital Inputs

There are three general purpose digital inputs on GV305CEU. They are all negative triggers.

Table 6. Electrical Characteristics of Digital Inputs

Logical Status	Electrical Characteristics
Active	0V to 0.6V
Inactive	Open

The following figure shows the recommended connection of a digital input.




Figure 9. Typical Digital Input Connection

3.9. Analog Inputs

There are three analog inputs on GV305CEU, and the analog input voltage ranges are 0-16V and 0-30V. The following figure shows the recommended connection.



Figure 10. Typical Analog Input Connection

Note:

1. For PIN 12 and PIN2, the voltage range is 0-16V.
2. For PIN 1, the voltage range is 0-30V.

3.10. Digital Outputs

There are six digital outputs on GV305CEU. All three digital outputs are of open drain type and the maximum drain current is 150mA. Each output has the built-in over current PTC resettable fuse.




Figure 11. Digital Output Internal Drive Circuit

Table 7. Electrical Characteristics of Digital Outputs

Logical Status	Electrical Characteristics
Enable	<1.5V @150 mA
Disable	Open drain




Figure 12. Typical Connection with Relay




Figure 13. Typical Connection with LED

Note:

1. OUT1 will latch the output state during reset.
2. Many modern relays come with a flyback diode pre-installed internal to the relay itself. If the relay has this diode, please ensure the relay polarity is properly connected. If this diode is not internal, it should be added externally. A common diode such as a 1N4004 will work in most circumstances.

3.11. Device Status LED



Figure 14. GV305CEU LED on the Case

Table 8. Definition of Device Status and LED

LED	Device Status	LED Status
BLE	The device's Bluetooth is scanning.	Red LED fast flashing
	The device's Bluetooth is broadcasting.	Red LED single slow flashing
GNSS	GNSS chip is powered off.	Blue LED OFF
	GNSS sends no data or data format error occurs.	Blue LED slow flashing
	GNSS chip is searching GNSS information.	Blue LED fast flashing
	GNSS chip has gotten GNSS information.	Blue LED ON
CEL	Device is searching network.	Green LED fast flashing
	Device has been registered on the network.	Green LED slow flashing
	SIM card needs pin code to unlock.	Green LED ON
PWR	No external power and internal battery voltage is lower than 3.6V.	Red LED OFF
	No external power and internal battery voltage is lower than 3.7V.	Red LED slow flashing
	The external power supply has been connected to the device and the internal battery of the device is charging.	Red LED fast flashing
	The external power supply has been connected to the device and the internal battery of the device is fully charged.	Red LED ON

Note:

1. CEL LED, GNSS LED and PWR LED can be configured to be turned off after a period time by using the configuration tool.
2. Fast flashing: For CEL LED, it is about 60 Ms ON/780 Ms OFF. For GNSS LED and PWR LED, it is

about 100 Ms ON/100 Ms OFF.

3. Slow flashing: For CEL LED, it is about 60 Ms ON/1940 Ms OFF. For GNSS LED and PWR LED, it is about 600 Ms ON/600 Ms OFF.

3.12. Serial Port/UART Interface

There are two lines dedicated to the Serial Port/UART interface (TXD and RXD). TXD/RXD is standard RS232 signal.




Figure 15. Typical Connection with RS232 Port

3.13. 1-WIRE Interface

There are two lines dedicated to the 1-WIRE, one is VDD-1-WIRE and the other is DATA-1-WIRE. The following diagram shows the recommended connection of 1-wire device.






Figure 16. 1-WIRE Interface

Note:

1. Before connecting and removing accessories, please power off the device first.
2. Please keep the voltage on the VDD-1-WIRE and DATA-1-WIRE to no more than 5.5V when using 1-WIRE.
3. Avoid short circuits in VIN (or high voltage signal cable), GND and VDD_1_WIRE/DATA signal cables. Short circuits may damage the 1-WIRE chip and cause device abnormality.
4. When the 1-WIRE function is not used, please wrap the VDD_1_WIRE/DATA signal cable with insulation tape to avoid contact with other high-voltage signal cables or GND.



5. When using ONE-WIRE, please wrap the VDD_1_WIRE/DATA connection with insulation tape.



3.14. Motion Sensor Direction

GV305CEU has an internal 3-axis accelerometer supporting driving behavior monitoring, crash detection and motion detection. The following figure shows the directions of the motion sensor.



Figure 17. Motion Sensor Direction

Note:

1. The opposite direction of the cable bundle is the positive direction of the X-axis.
2. The Z-axis is in the positive direction above the label surface.
3. The positive directions of the three axes are perpendicular to each other, as shown in the figure.

3.15. RS485 Interface

There is one RS485 interface, RS485A/RS485B.



Figure 18. RS485 Interface